



## Bathroom Hardware

**NERVAL CORPORATION** Care & Maintenance documents provide guidelines on how to care for your NERVAL product. Failure to comply with NERVAL’s Care & Maintenance documents voids product warranty.

Over time, frequency of use may cause the finishes of your bathroom hardware to age in appearance. Also, prolonged exposure to cleaning chemicals and humidity may cause some signs of wear or tarnishing. These finish changes are regarded as normal wear and tear, and are not considered manufacturing defects. Following these care & maintenance instructions will guard your bathroom hardware products from excessive wear, and preserve the quality of your finishes.

There is a proper and improper way of cleaning your bathroom hardware. Here’s what you *don’t* want to do:

- *Don’t* use coarse or old rags or sponges. Doing so can cause rust to appear.
- *Don’t* use bleaches and acidic cleaners to clean your bathroom hardware. This is too harsh and can cause damage to the finish of the material.

In order to keep your hardware looking and functioning properly, you should do the following:

- Use a cloth moistened with a gentle all-purpose cleaner to clean your bathroom hardware. Mild soap and warm water work well too. For best results, dry immediately with a soft, clean cloth.

03/22/2020