

**NERVAL CORPORATION** Care & Maintenance documents provide guidelines on how to care for your NERVAL product. Failure to comply with NERVAL's Care & Maintenance documents voids product warranty.

### Humidity and Temperature

It is suggested that the ideal range of temperature for furniture is 70°F to 72°F (21°C to 22°C) with humidity levels kept within a range between 40% and 50%. This humidity and temperature range applies to wood veneer furniture and laminate furniture.

### Wood Veneer Furniture

#### Use and Care

- Keep furniture out of direct sunlight.
- Avoid placing furniture in front of or under windows.
- Place furniture away from heating and air conditioning vents.
- Blot up spills immediately.
- Dust your furniture regularly and polish every 4-6 months.
- Place protective pads on desks and other surface on which writing or other activities would occur.
- Use felt on the bottom of lamps, vases, and other accessories to prevent scratching surfaces.
- Avoid using household solvent-based products such as fingernail polish and polish removers around an unprotected finished surface. In case of spills, blot the spill immediately, do not wipe as this will spread the spill and may cause further damage. If the finish has been damaged, call a professional for an evaluation.

#### Cleaning and Polishing

- Cleaning your wood furniture regularly will help maintain the value of your furnishings.
- Dusting and cleaning removes the build up of grease, lint and dust that can get ground into and damage the finish.
- Cleaning your furniture should be done with a soft lint free cotton or microfiber cloth dampened with water or furniture polish following the pattern of the grain. Use a light touch and rotate your cleaning cloth frequently. Follow by using a quality furniture polish to protect the cleaned surface per the manufacturer's instructions.

#### Metals

- Never use cleaners with alcohols or solvents on metals.
- Only used fine cotton or extra soft cloths. We recommend that tarnished metals be professionally cleaned.
- Polished Metals or polished stainless should be wiped with a damp cloth. Do not use commercial or heavy duty polishes or waxes, as they may scratch or damage the finish.

### Laminate Furniture

#### Use and Care

- Regular dusting with a soft cloth is the best way to keep your laminate furniture clean. Avoid wet wiping – it will leave marks, and the moisture may warp the laminate if not immediately and thoroughly dried.
- Fingerprints on laminate can be removed with a soft dry cloth most of the time. For greasy fingerprints, try dampening the same cloth and dry the area immediately after
- For any marks that are visible after dusting, use a soft sponge, slightly dampened, and immediately dry. Avoid varnish, wax or polish for laminate furniture.
- Even when you use a mild cleaning solution, avoid applying it to the surface directly- it may stain your furniture. Spray the solution on your cleaning mop or pad and clean with the damp pad, then dry.
- Detergent based cleaners can also leave a dull film on your furniture. Never allow water or any solution to sit for long.
- Use mats and coasters to protect furniture surfaces from stains, spills and excess heat.

03/22/2020